

Designed by Greta Grossman

PRODUCT



Item no.: 005-0230X
+ style code

DESCRIPTION

The classic Cobra lamp takes its name from the shape of the oval shade, which is reminiscent of a Cobra's neck (or hood). The tubular flexible arm can be bent in all directions whilst the shade can be rotated through 360°. The base is covered in powder-coated steel and weighted with cast iron stand. Switch integrated in the base.

VERSION - COBRA TABLE LAMP GM2

RAL codes are indicative.

- Fabric wire - Black:
- Vintage red / White inside // RAL 3012 / RAL 9003 // Gloss level 20 / Gloss level 20
- Anthracite grey / White inside // RAL 7016 / RAL 9003 // Gloss level 20 / Gloss level 20
- Blue grey / White inside // RAL 160 60 05 / RAL 9003 // Gloss level 20 / Gloss level 20
- Jet Black / White inside // RAL 9005 / RAL 9003 // Gloss level 20 / Gloss level 20


- Fabric wire - White:
- Warm grey / White inside // RAL 085 60 10 / RAL 9003 // Gloss level 20 / Gloss level 20
- Matt white / White inside // RAL 9003 / RAL 9003 // Gloss level 20 / Gloss level 20

VERSION - COBRA TABLE LAMP GM2

Order item - look for part number in the pricelist.

Series contains the following:

GM1, GM2, GM3



COLOURS



// Warm grey



// Vintage red



// Anthracite grey



// Blue grey



// Jet Black



// Matt white

FACTS

MEASUREMENT - L X W X H MM

- Lamp height: 13,5 inches
- Lamp stand diameter: 6,6 inches
- Shade height: 3 inches
- Shade depth: 11,4 / 6,5 inches
- Cable length, exposed: APP. 65,7 inches
- Cable length, total: APP. 84 inches

WEIGHT ITEM - LAMP INCL. WIRE

5,7 lb

PACKAGING TYPE

Cardboard box

PACKAGING MEASUREMENT - L X W X H inches

L:15,7 X W: 13,8 X H:19,7 inches

WEIGHT PACKAGING - MATERIAL TYPE (recyclable)

- Delivery note: 0,35 oz
- LD-EPE foam: 0,17 oz
- Paper egg crate: 2,9 lb
- PE polybag: 0,07 oz
- Cardboard inside: 2,2 lb
- Cardboard outside, 5ply Corrugated: 2,2 lb

WEIGHT PACKAGING - TOTAL

13 lb

NUMBER OF PARCELS

1 pcs.

Designed by Greta Grossman

ACCESSORIES

-

ENVIRONMENT

-

TESTS

-

CERTIFICATION AND LABELS

CUL-APPROVED

SAFETY INSTRUCTIONS

If the cord or plug is damaged, unplug it from the socket with dry hands. Do not use the lamp until it is repaired by a qualified Electrician.

Instructions document: No. 53-15-005-01

BULB REPLACEMENT

- Disconnect the power before replacing bulb.

TROUBLE SHOOTING

- If lamp does not light, turn off the power. Check the bulb for a broken filament. Replace bulb if necessary, then turn it on.
- If the lamp still does not light, please contact customer service at the local dealer.
- If the incandescent flexible cable or cord of this lamp is damaged, it must be replaced by a qualified electrician in order to avoid a hazard.

MAINTENANCE

- Unplug power cord prior to maintenance.
- To clean, use a soft cloth only.
- Do not use any chemical or abrasive cleaners.

GUBI®

Cobra Table Lamp

005-023xx

GUBI A/S
 Høxbølvej 7-9 / Platanus 53 T +45 3332 6308
 2150 Nordhavn, Copenhagen CVR: 17942884
 Denmark WWW.GUBI.DK

Step 1

- 1 Unpack lamp.
- 2 Place on stable ground.


Step 2

- 3 Plug lamp to mains voltage.
- 4 Push switch to turn lamp on and off.

53-15-005-01 Mounting instr. Cobra Table Lamp US

LIGHT SOURCE:

- Socket: E12 base
- Bulb types recommended:



- Recommended light sources: *Halogen light bulb*
 - Recommended wattage: 46 W
 - Max wattage: 46 W

- All fluorescens light bulbs*
 - Recommended wattage: 15 W
 - Max wattage: 15 W

- LED retrofit light bulbs*
 - Recommended wattage: 7 W
 - Max wattage: 9 W

- *Max. light out put for above lamps:*
- *800 Lumens = (60WATT incandescent bulbs)*

- All lamps can be fitted with a dimmer -Please contact your local electrician.

- Lightbulb not included
- *US plug: Type A, 2 PIN, 15 amp, (NEMA 1-15)*
- *US voltage: 120 V*
- *Frequency: 60 Hz*
- *Supply voltage: AC power ~*
- *Normally Closed: IP20*



Class II / Double insulated



Mark for Canada and the U.S.



Luminaires accepted for mounting on a flammable base

GUBI®

COBRA LAMP // Designed by Greta Grossman

DK
 Tillykke med din Cobra lampe designet af Greta Grossman i 1950. Vi håber du vil blive glad for den.
 Efter et stykke tid vil du muligvis opleve, at ledet på skærmen bliver løst og her bring for efterspænding. Dette gøres ved hjælp af den medfølgende spændingsglede.
 Placer spændingsgleden ind over flex arm. Før spændingsgleden frem til omklæberen og døj den med uret rundt.
Obs: Undlad at rotere skærmen gentagne gange om sine egne akse, da det kan forårsage defekte.

ENG
 Congratulations with your Cobra lamp designed by Greta Grossman in 1950. We hope you will enjoy it.
 After some time you may find that the joint on the shade will get loose and needs tightening. This can be done by using the included wrench. Place the wrench over the flex arm. Move it forward to the nut and turn it clockwise.
Caution: Do not rotate the shade repeatedly on its axis, as this might result in malfunctioning.

DE
 Gratulation zu Ihrer Cobra Leuchte Entworfen 1950 von Greta Grossman. Wir wünschen Ihnen viel Freude damit.
 Bitte beachten Sie, dass sich die Verbindungen im Laufe der Zeit lockern können und nachgezogen werden müssen. Verwenden Sie dazu bitte beiliegendes Schraubenschlüssel. Positionieren Sie denselbe oberhalb des flexiblen Arms und drehen Sie die Mutter im Uhrzeigersinn los.
Achtung: Bitte drehen Sie den Schirm nicht mehrmals um seine Achse, dies verursacht einen Defekt.